

Cascade Auto-Start Controller Installation and Operations Manual Version: 1.01

00-02-0587
Revised 03-11-05
Section 40



Please read the following information before installing. A visual inspection of this product for damage during shipping is recommended before mounting. It is your responsibility to have a qualified person install this unit and make sure it conforms to NEC and local codes.

GENERAL INFORMATION

WARNING

BEFORE BEGINNING INSTALLATION OF THIS MURPHY PRODUCT

- ✓ Disconnect all electrical power to the machine.
- ✓ Make sure the machine cannot operate during installation.
- ✓ Follow all safety warnings of the machine manufacturer.
- ✓ Read and follow all installation instructions.

Description

The Cascade controller offers automatic start/stop control with easy configuration for a broad number of engine driven applications.

Specifications

- Power input:** 9-35VDC continuous - operates during total blackout for 2 sec. min.
 - Power consumption:** Sleep Mode (Manual): 1mA typical;(Automatic) 4mA typical. Running Mode (Manual): 20mA typical; (Automatic): 24mA typical.
 - Operating/Storage temperature:** -40 to 85°C; (-40 to 185°F).
 - Humidity:** 0-100%, non-condensing.
 - Housing:** UV stabilized black polycarbonate and epoxy encapsulation. Weather tight and includes sealing gasket to keep moisture and debris out of enclosure. Properly mounted controller will maintain NEMA4 / IP65 rating of enclosure.
 - Vibration:** Rated to 6G.
 - Impact:** Rated to 10G.
 - Inputs:** Dedicated digital inputs for low oil pressure, high engine temperature, remote start, DC charge fail/Alternator fail. Two aux inputs are configurable for multiple functions.
 - Outputs:** 7 – 4 auxiliary, configurable (2A DC protected). 3 dedicated outputs for Crank, Fuel/ECU, Alternator excitation.
 - Crank attempts:** 3, 5, 10, Continuous.
 - Crank Rest:** 5-60 seconds, adjustable.
 - Shutdown lockout time delay:** 5, 10, 15, 20, 25, 30 seconds.
 - Crank disconnect speed setting:** Field settable 0-9999 RPM (16-60Hz AC freq input).
 - Overspeed/underspeed trip point setting:** ±5 to 50% of nominal.
 - Speed sensing inputs:** Magnetic pickup (5-120VAC RMS / 0-10 kHz) & AC frequency (30-600VAC RMS / 16-80 Hz).
 - CANbus interface:** Directly reads engine speed, & engine status data* from SAE-J1939 enabled engines.
 - MODbus interface:** In J1939 applications drives PVA series analog gages
- *Engine status data limited to low oil pressure, high engine temperature, "Wait to start" status, Warning & Fault lamp information, and communication error.

To Install, You Will Need:

- #2 Phillips (cross head) head screwdriver
- Nut driver to fit #6-32x1/2" machine nuts
- Wire for hook-up (rising cage clamp suitable for 14-24 gage wire).

MURPHY, the Murphy logo, Cascade, and SWITCHGAGE(r) are registered and/or common law trademarks of Murphy Industries, Inc.


This document, including textual matter and illustrations, is copyright protected by Murphy Industries, Inc., with all rights reserved. (c) 2004 Murphy Industries, Inc.

Mounting the Cascade

Cut a 5.63 x 4.06 in. (143 x 103mm) mounting hole, and drill four 0.169 in.(4.3 mm) diameter holes for the mounting screws. See Schematic below:

Cut Out Dimensions

5.63 x 4.06 in. (143 x 103 mm).



Recommended Wiring Practices



Warning: The CASCADE is designed for pilot-duty use and its outputs are for control only. Wire the CASCADE controller with 18 gage stranded wire.
Important: For applications involving automatic start equipment, we strongly recommend the installation of an appropriate Emergency Stop device.

1. To help prevent electrical noise and voltage drop to the controller during cranking and preheat, wire the controller DC power connections directly to the cranking battery. This will also help improve "Low battery" starting capability.
2. When using a battery charger, it should be connected directly to the battery to help prevent electrical noise which could cause an engine ECU or associated equipment to operate erratically.
3. Never route low voltage DC wiring in the same conduit as high voltage AC wiring. Noise from electrical loads such as motors and variable frequency drives can be coupled into the engine ECU, governor, or associated equipment and may cause erratic operation.
4. Always use twisted shielded pair wires for the magnetic pickup wiring. Ground one end of the shield only.
5. In spark ignited engine applications, always use resistive spark plugs and spark plug wires, as these greatly reduce the amount of radiated noise.
6. Always place a snubbing diode (sometimes also called an anti-flyback, anti-kick-back or reverse bias diode) directly across any inductive load. This helps eliminate a common source of electrical noise, as well as increases the operating life-time of any solid state output.
7. Always use twisted shielded pair communications wiring for RS-485, and SAE standard wire for J1939. Make sure that terminating resistors (if required) have the correct rating and are installed properly.

LED Status Lights

Eleven LEDs separated into two banks (see “Fig. 1”) are provided on the faceplate. The LEDs Bank 1 includes 6 LEDs and Bank 2 includes 5. In Setup mode, these banks form a binary code to indicate either the controller setup configuration or error status, which is indicated by the last 8 (red) LEDs. Refer to Tables 1, 2, 3 and 4 for configuration and status listings.

One LED is located next to the “AUTO” button to indicate that the controller is waiting for the remote start input to become active.

The LED status light are (from top to bottom) see “Fig. 1”:

Engine running - If the green LED is ON, then the unit is receiving a speed signal, indicating that the engine is above the crank cut speed.

ECU status - If the green LED is on solid, it indicates that in a J1939 application the ECU and the unit are communicating properly. If the LED is blinking slowly the ECU is broadcasting a “wait to start” message. If the LED is blinking fast, the ECU is NOT communicating properly.

Remote Start/ Crank Rest - If the green LED is on, then the remote start input is active and if the system is in AUTO mode, it will try to start. If the LED is blinking, the crank cycle has ended and is now in crank rest cycle.

Low oil pressure - If the red LED is on, the controller has caused the engine to shut down and lockout. If the LED is blinking, the engine ECU has transmitted a SPN for an oil pressure related condition.

High Engine Temperature - If the red LED is on, the controller has caused the engine to shutdown and lockout. If the LED is blinking, the engine ECU has transmitted a SPN for an engine temperature related condition.

Overspeed - If the red LED is on, the controller has caused the engine to shutdown and lock out due to engine speed exceeding the setpoint.

Underspeed - If the red LED is on, the controller has caused the engine to shutdown and lock out due to engine speed falling below the minimum needed for proper operation.


Overcrank - If the red LED is on, the controller has exceeded the set number of start attempts without receiving a valid speed signal indicating that engine speed is above crank disconnect. This causes the engine to shutdown and lockout.

Charge Fail - If the red LED is on it indicates that the battery charging alternator is not charging the cranking batteries, or that the battery charger fail output is on.

Aux 1 - If the red LED is on it indicates that this custom-configured input is active. On an ECU (ECM) equipped engine, if this LED is blinking slowly, it indicates that one or more engine parameters are near exceeding engine manufacturer’s setpoints. If the LED is blinking fast, it indicates that one or more engine parameters have exceeded setpoints, the ECU has issued a fault - and most likely the engine has shut down.

Aux 2 - If the red LED is on it indicates that this custom-configured input is active.

Overspeed & Underspeed - If these two LED’s are both blinking, the controller has lost its speed signal.



Setting Up the Cascade

- To enter the **SETUP MODE** first remove DC power to the Cascade controller for approximately 10 seconds.

- On the back of the controller are four DIP switches, set switch #1 to ON (see schematic at right) then restore DC power. The AUTO mode LED will blink to indicate that the Cascade is in the **SETUP MODE**.

- When in the “**SETUP**” mode, pressing the “**MAN**” (Manual) button steps up thru the entire list of parameters. The pattern of the top six LEDs, **LEDs Bank 1** (see “**Fig. 1**”), is used to indicate which parameter is selected. The pattern will change once each time the “**MAN**” button is pressed.
- Pressing the “**OFF**” button steps up thru all the available values for each parameter. The pattern of the bottom five LEDs, **LEDs Bank 2** (see “**Fig. 1**”), is used to indicate which value is selected. The pattern will change once each time the OFF button is pushed.

- Pressing the “**AUTO**” button stores the displayed value.


- If any value is changed, it will blink until stored, except a value of zero. If any value is changed but not stored, and then the parameter is changed, the value will still be what was shown originally.

- If you accidentally go past a desired parameter or value, you can step back by pressing the down arrow button.

- The parameter/value list and corresponding LED indication are shown on Table 1.

- When you are finished with setup, set switch #1 to in the Normal Operating Position (OPEN), remove DC power for 10 seconds, then restore DC power.

Move Switch toward the numbers to Turn On



NOTE: Switch settings are read at Power Up only.

Fig. 2




Fig. 3

Operating the Cascade

When power is first applied, all LEDs will flash indicating a Lamp Test function.

- To manually start the engine, press the “**MAN**” (Manual) button. The controller will initiate a normal start sequence.
- To manually stop the engine (or turn off the controller) press the “**OFF**” button.
- To place the controller in automatic mode, press the button labeled “**AUTO**”. The LED next to the “**AUTO**” button should come on to indicate that the controller is waiting for the remote start input to become active to initiate a start sequence.
- To reset the controller, press the “**OFF**” button. Then correct the cause of the shutdown. This will clear all faults except when the aux inputs are programmed for either shutdown immediate or warning immediate, or if the engine ECU is broadcasting a shutdown fault.

In the event of a fault that causes the engine to shutdown, the cause of the event will be indicated on one of the 11 status lights on the right hand side of the controller. When the cause of shutdown is corrected, the controller can resume normal operation.

Modes of Operation

Setup Mode (See “Setting Up The Cascade” section, above and “**Table 1**”).

Normal Operating Mode (Engine Control Mode)

The DIP switch #1 must be in the open position in order to enter this mode upon power up. The “**Table 2**” shows the meaning of each LED state for this mode.

Error Mode

Upon power up, when the DIP switch #1 is in the Normal Operating Position (open position) and an error is detected in the user configuration, the Error mode will be accessed. The LEDs will Blink Fast indicating the error. To correct the errors before the unit can operate in Engine Control mode, the user will need to go back to Setup mode. “**Tables 3 and 4**” show the meaning of each LED state and configuration for the Error mode.

Table 1. Parameter Values and Corresponding LED Indication

LEDs shown here form a binary code indicating the configuration value. Shown from Top to bottom the LEDs read from Left to Right (see Fig.1). A filled dot means LED is ON.

Parameter	LED Bank 1	Value (*= default)	LED Bank 2	Parameter	LED Bank 1	Value (*= default)	LED Bank 2
Engine Speed Source	○○○○●	Magnetic Pickup* Generator AC J1939	○○○○○ ○○○○● ○○○○○			5 Min 6 Min 7 Min 8 Min 9 Min 10 Min 15 Min 20 Min 25 Min 30 Min 35 Min 40 Min 45 Min 50 Min 55 Min 1 Hr	○○●●● ○○●○○ ○○●○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○ ○●○○○
Crank Attempts	○○○○●	3* 5 10 Continuous	○○○○○ ○○○○● ○○○○○ ○○○○●				
Crank Timer	○○○○●	5 Sec 10 Sec 15 Sec* 20 Sec 25 Sec 30 Sec 45 Sec 60 Sec	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○●				
Crank Rest Timer	○○●○○	5 Sec 10 Sec 15 Sec* 20 Sec 25 Sec 30 Sec 45 Sec 60 Sec	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○●	Remote Start Signal Type	○○●●●●	Maintained* Momentary	○○○○○ ○○○○●
				Digital Input 1	○●○○○○	Lo Oil Press (Open/Fault) Lo Oil Press (Close/Fault)*	○○○○○ ○○○○●
				Digital Input 2	○●○○○●	Hi Eng Temp (Open/Fault) Hi Eng Temp (Close/Fault)*	○○○○○ ○○○○●
Start Delay Timer (auto mode only)	○○●○○	0 Sec* 5 Sec 10 Sec 15 Sec 30 Sec 60 Sec	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○●	Digital Input 3 (Auxiliary Input 1)	○●○○○●	Not Used* Winter/Summer Momentary Stop Immediate Warning Delayed Warning Immediate Shutdown Delayed Shutdown Delayed Aux Input Shtdwn Run/Idle (Line Fill) Auxiliary Crank Disconnect Remote Reset (Clear Faults)	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○●
Stop Delay Timer (auto mode only)	○○●○○	0 Sec* 5 Sec 10 Sec 15 Sec 30 Sec 60 Sec	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○●				
Preheat Timer	○○●●●	0 Sec* 5 Sec 10 Sec 15 Sec 20 Sec 25 Sec 30 Sec	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○	Digital Input 4 (Auxiliary Input 1)	○●○○○●	Not Used* Winter/Summer Momentary Stop Immediate Warning Delayed Warning Immediate Shutdown Delayed Shutdown Delayed Aux Input Shtdwn Run/Idle (Line Fill) Auxiliary Crank Disconnect Remote Reset (Clear Faults)	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○●
Extended Preheat	○○●○○○	0 Sec* 5 Sec 10 Sec 15 Sec 20 Sec 25 Sec 30 Sec	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○	Fuel Relay Control (non ECU Engines)	○●○●○○	Energized to Run* Energized to Stop	○○○○○ ○○○○●
Warmup Timer	○○●○○●	0 min.* 1 min. 5 min. 10 min.	○○○○○ ○○○○● ○○○○○ ○○○○●	Auxiliary Output 1	○●○●●●	Not Used* Warmup Cooldown Warmup/Cooldown Preheat Engine Running At Load Lo Oil Press Shutdown Hi Eng Temp. Shutdown Overspeed Shutdown Overcrank Shutdown Alternator Fail Engine Speed Up Engine Speed Down Common Alarm	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○●
Cooldown Timer	○○●○○○	0 min.* 1 min. 5 min. 10 min.	○○○○○ ○○○○● ○○○○○ ○○○○●				
Bypass Timer	○○●●●●	0 Sec 5 Sec 10 Sec* 15 Sec 20 Sec 25 Sec 30 Sec	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○	Auxiliary Output 2	○●●○○○	Not Used* Warmup Cooldown Warmup/Cooldown Preheat Engine Running At Load Lo Oil Press Shutdown Hi Eng Temp. Shutdown Overspeed Shutdown	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○ ○○○○●
Energize to Stop Timer	○○●●○○	15 Sec* 30 Sec	○○○○○ ○○○○●				
Aux Input Bypass Timer	○○●●○○	30 Sec* 1 Min 2 Min 3 Min 4 Min	○○○○○ ○○○○● ○○○○○ ○○○○● ○○○○○				

Table 1. Parameter Values and Corresponding LED Indication (continued)

LEDs shown here form a binary code indicating the configuration value. Shown from Top to bottom the LEDs read from Left to Right (see Fig.1). A filled dot means LED is ON.

Parameter	LED Bank 1	Value (* = default)	LED Bank 2	Parameter	LED Bank 1	Value (* = default)	LED Bank 2		
Auxiliary Output 3	●●●●●○	Overcrank Shutdown	○●○●○	Crank Disconnect RPM (ECU or MPU speed source only) (10's digit)	●○●○●●	0	○●○●○		
		Alternator Fail	○●○●●			1	○●○●○●		
		Engine Speed Up	○●●○●			2	○●○●○		
		Engine Speed Down	○●●○●			3	○●○●○●		
		Common Alarm	○●●○●			4*	○●○●○		
		Not Used*	○●○●○			5	○●○●○●		
		Warmup	○●○●○●			6	○●○●○		
		Cooldown	○●○●○			7	○●○●○●		
		Warmup/Cooldown	○●○●○●			8	○●○●○		
		Preheat	○●○●○			9	○●○●○●		
Auxiliary Output 4	○●●○●○	Engine Running	○●○●○●	Crank Disconnect RPM (ECU or MPU speed source only) (1's digit)	●○●○●○	0*	○●○●○		
		At Load	○●○●○			1	○●○●○●		
		Lo Oil Press Shutdown	○●○●○●			2	○●○●○		
		Hi Eng Temp. Shutdown	○●○●○			3	○●○●○●		
		Overspeed Shutdown	○●○●○●			4	○●○●○		
		Overcrank Shutdown	○●○●○			5	○●○●○●		
		Alternator Fail	○●○●○●			6	○●○●○		
		Engine Speed Up	○●○●○			7	○●○●○●		
		Engine Speed Down	○●○●○●			8	○●○●○		
		Common Alarm	○●○●○			9	○●○●○●		
Nominal Generator Frequency (genset only)	○●●●●○	Not Used*	○●○●○	Overspeed Setpoint (% above run speed)	●○●○●●	5%	○●○●○		
		Warmup	○●○●○●			10%*	○●○●○●		
		Cooldown	○●○●○			15%	○●○●○		
		Warmup/Cooldown	○●○●○●			20%	○●○●○●		
		Preheat	○●○●○			25%	○●○●○		
		Engine Running	○●○●○●			30%	○●○●○●		
		At Load	○●○●○			35%	○●○●○		
		Lo Oil Press Shutdown	○●○●○●			40%	○●○●○●		
		Hi Eng Temp. Shutdown	○●○●○			45%	○●○●○		
		Overspeed Shutdown	○●○●○●			50%	○●○●○●		
Crank Disconnect Freq (Generator AC speed source only) (10's digit) Lower Limit=16 Hz	○●●●●●	Overcrank Shutdown	○●○●○	Underspeed Setpoint (% below run speed)	●○●○●○	5%	○●○●○		
		Alternator Fail	○●○●○●			10%	○●○●○●		
		Engine Speed Up	○●○●○			15%	○●○●○		
		Engine Speed Down	○●○●○●			20%*	○●○●○●		
		Common Alarm	○●○●○			25%	○●○●○		
		50 Hz	○●○●○			30%	○●○●○●		
		60 Hz*	○●○●○●			35%	○●○●○		
		0	○●○●○			40%	○●○●○●		
		1	○●○●○●			45%	○●○●○		
		2*	○●○●○			50%	○●○●○●		
Crank Disconnect Freq. (Generator AC speed source only) (1's digit)	●○●○●○	3	○●○●○	Underspeed Response	●○●○●●	none	○●○●○		
		4	○●○●○●			Warning*	○●○●○●		
		5	○●○●○			Shutdown	○●○●○		
		6	○●○●○●			Lo Oil Press Shutdown Setpoint (ECU eng. only)	●○●○●○	Disabled (no shutdown)	○●○●○
		7	○●○●○					0 PSI	○●○●○●
		8	○●○●○●					5 PSI	○●○●○
		9	○●○●○					10 PSI	○●○●○●
		0*	○●○●○					15 PSI	○●○●○
		1	○●○●○●					20 PSI	○●○●○●
		2	○●○●○					25 PSI	○●○●○
3	○●○●○●	30 PSI*	○●○●○●						
4	○●○●○	35 PSI	○●○●○						
5	○●○●○●	40 PSI	○●○●○●						
Crank Disconnect RPM (ECU or MPU speed source only) (1000's digit)	●○●○●○	6	○●○●○	Hi Eng Temp. Shutdown Setpoint (ECU engines only)	●○●○●○	45 PSI	○●○●○		
		7	○●○●○●			50 PSI	○●○●○●		
		8	○●○●○			55 PSI	○●○●○		
		9	○●○●○●			60 PSI	○●○●○●		
		0*	○●○●○			Disabled (no shutdown)	○●○●○		
		1	○●○●○●			190 deg F	○●○●○●		
		2	○●○●○			195 deg F	○●○●○		
		3	○●○●○●			200 deg F	○●○●○●		
		4	○●○●○			205 deg F	○●○●○		
		5	○●○●○●			210 deg F	○●○●○●		
6	○●○●○	215 deg F	○●○●○						
7	○●○●○●	220 deg F	○●○●○●						
8	○●○●○	225 deg F	○●○●○						
9	○●○●○●	230 deg F*	○●○●○●						
Crank Disconnect RPM (ECU or MPU speed source only) (100's digit)	●○●○●○	235 deg F	○●○●○	Lo Batt Voltage Setpoint.	●○●○●○	Warning Disabled	○●○●○		
		240 deg F	○●○●○●			8.5V	○●○●○●		
		245 deg F	○●○●○			9.0V	○●○●○		
		250 deg F	○●○●○●						
		0	○●○●○						
		1	○●○●○●						
		2	○●○●○						
		3	○●○●○●						
		4	○●○●○						
		5*	○●○●○●						
6	○●○●○								
7	○●○●○●								
8	○●○●○								
9	○●○●○●								

Table 1. Parameter Values and Corresponding LED Indication (continued)

LEDs shown here form a binary code indicating the configuration value. Shown from Top to bottom the LEDs read from Left to Right (see Fig.1). A filled dot means LED is ON.

Parameter	LED Bank 1	Value (*= default)	LED Bank 2	Parameter	LED Bank 1	Value (*= default)	LED Bank 2	
		9.5V	○○○●●	Flywheel Tooth Count (MPU speed source only) (1's digit)	●●○○○○	0	○○○○○	
		10.0V	○○●○○			1	○○○○●	
		10.5V*	○○●●●			2	○○○●○	
		11.0V	○○●○○			3	○○○●●	
		11.5V	○○●●●			4	○○●○○	
		18.0V	○●○○○			5	○○●●●	
		19.0V	○●○○●			6	○○●●○	
		20.0V	○●○○○			7	○○●●●	
		21.0V	○●○○●			8*	○○●○○	
		22.0V	○●○○○			9	○○●●●	
		22.5V	○●●○○			Run Speed (ECU or MPU speed source only) (1000's digit)	0	○○○○○
		23.0V	○●●○○				1*	○○○○●
		23.5V	○●●○○				2	○○○●○
		23.5V	○●●○○				3	○○○●●
Hi Batt Voltage Setpoint.	●○○○○●	Warning Disabled	○○○○○	Run Speed (ECU or MPU speed source only) (100's digit)	●●○○○○	4	○○●○○	
		12.5V	○○○○●			0	○○○○○	
		13.0V	○○○○○			1	○○○○●	
		13.5V	○○○○●			2	○○○●○	
		14.0V	○○○○○			3	○○○●●	
		14.5V*	○○○○●			4	○○○●○	
		15.0V	○○○○○			5	○○○●●	
		16.0V	○○○○●			6	○○○●○	
		24.5V	○○○○○			7	○○○●●	
		25.0V	○○○○●			8*	○○○●○	
		25.5V	○○○○○			9	○○○●●	
		26.0V	○○○○●			Run Speed (ECU or MPU speed source only) (10's digit)	0*	○○○○○
		26.5V	○○○○○				1	○○○○●
		27.0V	○○○○●				2	○○○●○
28.0V	○○○○○	3	○○○●●					
29.0V	○○○○●	4	○○○●○					
30.0V	○○○○○	5	○○○●●					
31.0V	○○○○●	6	○○○●○					
Flywheel Tooth Count (MPU speed source only) (100's digit)	●●○○○○	0	○○○○○	Run Speed (ECU or MPU speed source only) (10's digit)	●●○○○○	7	○○○●●	
		1*	○○○○●			8	○○○●○	
		2	○○○○○			9	○○○●●	
		3	○○○○●			Fault Code SPN Conversion Method (ECU Eng. only)	●●○○○○	Version 1 & 4 *
Flywheel Tooth Count (MPU speed source only) (10's digit)	●●○○○○	0	○○○○○	Version 2 & 4	○○○○●			
		1	○○○○●	Version 3 & 4	○○○●○			
		2	○○○○○					
		3	○○○○●					
		4	○○○○○					
		5	○○○○●					
		6*	○○○○○					
		7	○○○○●					
8	○○○○○							
9	○○○○●							

Table 2. LED States for Normal Operating Mode

LED	OFF	ON	Slow Blink	Fast Blink
AUTO	Manual Start Mode	Auto Start Mode		
Engine Running	Engine is not Running	Engine is Running		
ECU Status	Non-ECU configuration	Valid CAN Activity (no errors, Error Active state)	Wait-to-Start	Bus Off/Error Passive/Failed Address Claim
Remote Start/Crank Rest	Remote start input is inactive and manual start has not been initiated	Remote Start active	In Crank Rest or one of the prestart states (startdelay, preheat, waitecu, wait rpm)	
Low Oil Pressure	Pressure is above setpoint or low oil pressure input is inactive	Pressure is below setpoint or low oil pressure input active	Fault code SPN 100 received AND ECU warning/shutdown active	No pressure data (ECU only)
High Engine Temperature	Temperature is below setpoint or high engine temperature input is inactive	Temperature is above setpoint or high engine temperature input is active	Fault code SPN 110 received AND ECU warning/shutdown active	No temperature data (ECU only)
Overspeed	Engine speed below overspeed setpoint	Engine speed above overspeed setpoint		No speed data (ECU) or loss of speed (non-ECU)
Underspeed	Engine speed above underspeed setpoint	Engine speed below underspeed setpoint		No speed data (ECU) or loss of speed (non-ECU)
Overcrank/Start Fail	Failure to start has not occurred	Overcrank start failure (crank attempts exceeded)	Start Condition Failure (RPM not below 10 or crank disconnect input is on before attempting crank)	Start Condition Failure (ECU-related) CAN Hw Bus Error preventing start
Charge Fail	Alternator warning lamp terminal voltage is above threshold or charge fail input is inactive	Alternator warning lamp terminal voltage is below threshold or charge fail input is active	Battery Voltage is below low voltage warning setpoint	Battery Voltage is above high voltage warning setpoint
Auxiliary 1	Auxiliary input 1 is inactive	Auxiliary input 1 is active	ECU Warning (malfunction or Amber lamps on)	ECU Shutdown (Red Stop or Protect lamps on)
Auxiliary 2	Auxiliary input 2 is inactive	Auxiliary input 2 is active		

Table 3. Error Codes LED States

LED	OFF	ON	Slow Blink	Fast Blink
Auto	(not used)	(not used)	(not used)	(not used)
Engine Running	(not used)	(not used)	(not used)	(not used)
ECU Status	(not used)	(not used)	(not used)	(not used)
Remote Start /Crank test	(not used)	(not used)	(not used)	(not used)
Low Oil Pressure	(not used)	(not used)	(not used)	ERROR CODE (MSB)
High Engine Temperature	(not used)	(not used)	(not used)	ERROR CODE
Overspeed	(not used)	(not used)	(not used)	ERROR CODE
Underspeed	(not used)	(not used)	(not used)	ERROR CODE
Overcrank/Start Fail	(not used)	(not used)	(not used)	ERROR CODE
Charge Fail	(not used)	(not used)	(not used)	ERROR CODE
Auxilliary 1	(not used)	(not used)	(not used)	ERROR CODE
Auxilliary 2	(not used)	(not used)	(not used)	ERROR CODE (LSB)

Table 4. Configuration Error Codes

The eight LEDs shown in the table below form an 8-bit binary error code to indicate the type of configuration error detected. The following error codes are currently defined:

Error Code(s)	LED Indication	Error
1 – 63	(varies)	Individual configuration parameter number is out of range. The number flashed indicates the configuration parameter number that is in error (see Table 1.)
128	●○○○○○○○	Configuration memory CRC error. The user will need to go back to configuration mode and resave at least one configuration parameter.
129	●○○○○○●	All three digits of flywheel tooth count are zero. This is not allowed.
130	●○○○○●○	Remote Start Signal Type is set to MOMENTARY but no auxiliary input is configured for MOMENTARY STOP.
131	●○○○○●●	One of the Aux outputs is configured for “SPEED UP” or “SPEED DOWN” but none of the other Aux outputs is configured for the opposite setting
132	●○○○○●○	Speed source is set to AC Frequency and Crank Disconnect Frequency is set to less than 10 Hz. Crank disconnect frequency must be greater than 10 Hz.
133	●○○○○●●	Speed source set to Mag Pickup and Crank Disconnect RPM < 10 RPM. Crank disconnect RPM must be greater than 10 RPM.
134	●○○○○●○	Run speed is less than or equal to crank disconnect RPM (non-genset engines)



FW Murphy

P.O. Box 470248
 Tulsa, Oklahoma 74147 USA
 +1 918 317 4100 fax +1 918 317 4266
 e-mail sales@fwmurphy.com
 www.fwmurphy.com

INDUSTRIAL PANEL DIVISION

P.O. Box 470248
 Tulsa, Oklahoma 74147 USA
 +1 918 317 4100 fax +1 918 317 4266
 e-mail sales@fwmurphy.com

MURPHY DE MEXICO, S.A. DE C.V.

Blvd. Antonio Rocha Cordero 300, Fracción del Aguaje
 San Luis Potosí, S.L.P.; México 78384
 +52 444 8206264 fax +52 444 8206336
 Villahermosa Office +52 993 3162117
 e-mail ventas@murphymex.com.mx
 www.murphymex.com.mx

FRANK W. MURPHY, LTD.

Church Rd.; Laverstock, Salisbury SP1 1QZ; U.K.
 +44 1722 410055 fax +44 1722 410088
 e-mail sales@fwmurphy.co.uk
 www.fwmurphy.co.uk




Printed in U.S.A.


In order to consistently bring you the highest quality, full featured products, we reserve the right to change our specifications and designs at any time.

Typical Wiring Diagrams

Basic Mechanical Engine or Engine ECU or Engine AC Speed Sensing




Inc/Dec Throttle, Line Fill Delay, Low Oil/Coolant Level, Preheat, Common Alarm



Typical Wiring Diagrams (continued)

Mechanical Engine MPU Source Throttling to Pressure, Low Liquid Level Shutdowns Warmup-Cooldown Output



Mechanical Engine Winter/Summer Switch, Preheat Output & Timer Run & Idle Switch Output

